



Rough Opening & Door Frame Dimensions

Interior Doors

Single Swing Doors

Double Swing Doors

Pocket Doors

Single Swing Doors			Double Swing Doors			Pocket Doors		
Door Size Foot - Inch	OD Frame Size W x H in inches	Rough Opening W x H in inches	Door Size Foot - Inch	OD Frame Size W x H in inches	Rough Opening W x H in inches	Door Size Foot - Inch	OD Frame Size W x H in inches	Rough Opening (BEFORE POCKET FRAME) W x H in inches
1668	19 1/2 x 81 5/8	20 x 82 1/2	3068	37 1/2 x 81 5/8	38 x 82 1/2	1668	18 3/8 X 81 5/8	37 x 84 1/2
1868	21 1/2 x 81 5/8	22 x 82 1/2	3468	41 1/2 x 81 5/8	42 x 82 1/2	1868	20 3/8 X 81 5/8	41 x 84 1/2
11068	23 1/2 x 81 5/8	24 x 82 1/2	3868	45 1/2 x 81 5/8	46 x 82 1/2	11068	22 3/8 X 81 5/8	45 x 84 1/2
2068	25 1/2 x 81 5/8	26 x 82 1/2	4068	49 1/2 x 81 5/8	50 x 82 1/2	2068	24 3/8 X 81 5/8	49 x 84 1/2
2268	27 1/2 x 81 5/8	28 x 82 1/2	4468	53 1/2 x 81 5/8	54 x 82 1/2	2268	26 3/8 X 81 5/8	53 x 84 1/2
2468	29 1/2 x 81 5/8	30 x 82 1/2	4868	57 1/2 x 81 5/8	58 x 82 1/2	2468	28 3/8 X 81 5/8	57 x 84 1/2
2668	31 1/2 x 81 5/8	32 x 82 1/2	5068	61 1/2 x 81 5/8	62 x 82 1/2	2668	30 3/8 X 81 5/8	61 x 84 1/2
2868	33 1/2 x 81 5/8	34 x 82 1/2	5468	65 1/2 x 81 5/8	66 x 82 1/2	2868	32 3/8 X 81 5/8	65 x 84 1/2
21068	35 1/2 x 81 5/8	36 x 82 1/2	5868	69 1/2 x 81 5/8	70 x 82 1/2	21068	34 3/8 X 81 5/8	69 x 84 1/2
3068	37 1/2 x 81 5/8	38 x 82 1/2	6068	73 1/2 x 81 5/8	74 x 82 1/2	3068	36 3/8 X 81 5/8	73 x 84 1/2

*RO WIDTH = DOOR CALL-OUT WIDTH + 2"
 *RO HEIGHT = DOOR CALL-OUT HEIGHT + 2 1/2"
 *Assumes standard 3/4" undercut

*ASSUMES SURFACE ASTRAGAL FOR LATCHING DOUBLE DOORS
 *ADD 1/2" TO RO FOR FULL EDGE ASTRAGAL STRIP
 *RO WIDTH = DOOR CALL-OUT WIDTH + 2"
 *RO HEIGHT = DOOR CALL-OUT HEIGHT + 2 1/2"
 *Assumes standard 3/4" undercut

*RO WIDTH = 2x DOOR CALL-OUT WIDTH + 1"
 *RO HEIGHT = DOOR CALL-OUT HEIGHT + 4 1/2"
 *Assumes standard 3/4" undercut

